

FLOAT YOUR BOAT LIFT



THREE STANDARD SIZES

The size of system that's best for you depends on how wide your boat lift is between the inside of the vertical columns. If you're unsure, you can provide us with the make and model number of your lift.







INFLATABLE AIRBAGS THAT MAKE BOAT LIFT INSTALLATION AND REMOVAL EASIER



Easy-In Spring Installation



Adjusting Legs and Leveling Lift



Mid-Season Water Level Changes



Easy-Out Fall Removal









SYSTEM INCLUDES

- 2x airbags (color varies)
- Stainless steel & brass hardware
- 3x mounting points/airbag
- 12x 6" adjustable mounting L-brackets
- 40' air hose
- Hose straps
- Coupler kit
- 2x air valve assemblies









ACCESSORIES

- Inflator 120v 3.6PSI
- Wheel kit
- Buddy bag kit
- Top cover
- Full cover
- No fishing sign
- Stop brace
- Bracket shield
- Spacers/Blocks
- Taller/stronger L-brackets
- Air gauge kit
- Inverter
- Counter balance bag
- Repair Kit



9205 County Road 19 Corcoran, MN 55<u>357</u>

p: 763.498.7543

e: donnie@boatlifthelper.com



